


Firmware Upgrade LED Light Source

Connect the light source with USB to PC. Push encoder and keep it pushed while turning on the device. Reply below question by turning the encoder to select "YES" and push encoder to confirm.



After that in Microsoft Windows a new drive is displayed into which the new firmware file (.bin) has to be copied. Then please disconnect the USB cable from the light source.



When prompted for update select "YES" and confirm with encoder push. The update is confirmed by "Update successful". The light source can be used after pushing the encoder.